


FRONT DETAIL



FRONT DETAIL

<u>ITEM</u>	<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>
1	1	BELT GUARD	ASP1011
2	1	ENGINE	RP03424
3	2	BELT	RP03546
4	1	ELECTRIC CLUTCH	RP03547
5	1	PUMP	RP03542
6	1	BATTERY CABLE	RP03386
7	1	STRAINER ASSY. #2	RMC2511
8	1	LIGHT	RP03548
9	1	BATTERY	RP03217
10	1	FRONT AXLE ASSY.	ASP1032
11	2	WHEEL CENTER	RP03549
12	2	FRONT TIRE	RP03550
13	1	PUMP CONTROL CABLE	RP03180
14	2	LEAF SPRING ASSY.	RP03290
15	1	TIE ROD	RMB1363
16	2	LEAF SPRING EYE PLATE	RP03164
17	1	BATTERY CABLE	RP03452
18	2	LEAF SPRING HANGER	RP03167
19	1	PUMP	RP03536
20	1	FUEL TANK ASSY.	ASP1036
21	1	PUMP	RP03535
22	1	FUEL TANK CAP	RP03288
23	1	HYDRAULIC TANK	RMC1062
24	1	HYDRAULIC TANK CAP	RP03551